
#### Recorder



The Recorder works similar to a Sky Video Recorder. You can record at the same time as playing back. In addition it will automatically reverse when reaching either end of the recording on playback. Each Connection will create a separate recorder, you can make a separate recording of any or all connections simultaneously.



## **Starting Recording**

To use the recorder, you must first Create a recorder for the Connection you wish to record. Do this by Right Clicking on the name of the Connection on the main window. You can only record Connections which Output data.

## **Controls**

Rec	Record	Press to start recording Press again to Stop recording
<b>&lt;&gt;</b>	Playback	Press to play back Press again to reverse playback direction.
II	Pause	Press to pause playback only
<b>&lt;&lt;</b>	Reverse	Press to reduce playback speed Each press halves the speed
>>	Forward	Press to increase playback speed Each press doubles the speed
Stop	Stop	Press to stop playback only

# **Displays**



To close the recorder (on a Connection) click the

256



Playing back at 256 messages a second

#### Other Information

The recording is held in a file called Recorder\_connection name.rec where connection name is the name of the connection., for example Recorder\_OpenCPN.rec. The file is in the users Temp directory. At the moment there is no provision to "Save" additional recordings. The file is specially formatted including the time each message is recorded. It is not a plain text file like a log file, so you cannot use a log file to playback through the recorder. I may look at providing this facility in the future.

When you restart Recorder, if a recording exists for the selected Connection you will be asked

